

#80912 & #80915 - Motor Protector for the Traxxas Bandit, e-Rustler, e-Stampede & Slash

Important Note: The **RPM** Motor Protector must be used with either an **RPM** Rear Bumper Mount / Wheelie Bar Mount (**RPM #80902** or #80905) or a Traxxas mount (Traxxas #3677).

Before You Begin: If you have a wheelie bar or rear bumper mounted to the vehicle, it must be removed. If your vehicle did not come with or have a rear bumper mount or wheelie bar mount, one must be installed. Follow the instructions that came with your mount and install it prior to installing the **RPM** Motor Protector.

Installation: Slide the two screws supplied with this kit into the screw holes in your new **RPM** Motor Protector. With the **RPM** logo on the Motor Protector readable from the rear of the vehicle, install the Motor Protector on to the two bosses (**RPM** bumper mount) or over the two holes (stock Traxxas bumper mount) on the driver's side of the rear bumper mount / wheelie bar mount. Thread until snug - do not over-tighten the screws! If you are installing a second protector, simply follow the same instructions as above but mount to the two screw holes on the opposite side of the bumper mount (passenger side).