



T10PX Accessory Parts



T10PX Screen Protector

Features

- *Protect the screen from scratches and dirt.
- *It's a little smaller than the T10PX screen size, so that is easier attach and stick tight.
- *The protector has a front and back backing.



How to attach the protector

1 Clean your screen using a glass cleaner with a lint-free microfiber cloth. Wipe off the dust from the screen thoroughly before applying the screen protector.



(Dust and dirt are the reasons for air bubbles underneath the protector.)

2 Remove one side of the plastic backing. Along one edge about one inch and fold down the backing to expose the protector. Be careful not to touch the screen protector. Align the screen protector along the edge of the screen.

Be sure to attach the exposed one inch of the protector film straight to the screen.

Press the clean screen protector gently and steadily, press on the screen surface as you peel the backing away. Or gently slide a credit card over the surface, use as a squeegee to get as many of the air bubbles out for you. Slowly press out any air bubbles.

3 After attaching the protector is done. Remove the front backing.



FUTABA CORPORATION

Hobby Radio Control Business Center Sales & Marketing Department
1080 Yabutsuka, Chosei-mura, Chosei-gun, Chiba-ken, 299-4395, Japan

TEL: +81-475-32-6051, FAX: +81-475-32-2915 ©FUTABA CORPORATION 2021, 12 (1)